

Battery low alarm in Alarm Monitoring

Last Modified on 02/04/2022 10:49 am EST

Symptom

The "Low Battery" status does not reset as expected after the on-board battery is replaced on an LNL-2210, -2220, or -3300.

Resolution

To reset the status, remove power from the board and then reapply power. The status should return to normal.

Applies To

OnGuard all versions

Additional Information

The ISC resets on its own after a 24 hour period as well, thus clearing the "Low Battery" status.
